

VE522WCN

Enduraflex™ white, soft, top half chlorobutyl, bottom half pure gum (PG70) natural rubber for concentrated HCl and general purpose chemical services. Available with tie gum. Exhaust steam or pressure cure.

SPECIFICATIONS

FACE MATERIAL DUROMETER, ATMOSPHERIC CURE:
40 to 55 A

PRESSURE CURE:
40 to 50

AVAILABLE GAUGES:
3/16", 1/4", 4mm, 5mm, 6mm

SKIVE:
Closed

REPAIRS:
Repair with original lining.
See Section 16 – Repair Procedures.

TYPICAL PHYSICAL PROPERTIES		
Tensile Strength PSI	ASTM D412	1000
% Elongation at Break	ASTM D412	550
Durometer	ASTM D2240	52 A
Specific Gravity	ASTM D297	1.50
Adhesion to Metal	ASTM D429	30 LBS

Note: This lining is very easy to apply and may be used for HCl vapor area overlay in rail cars lined with PG70 and locations that require ozone and oxidation resistance.

CURE METHODS AND TIMES:	
Autoclave	1 hour at 260°F (127°C)
Internal Pressure	6 hours at 260°F (127°C)
	For insulated vessels, 2 hours at 235°F (113°C). is recommended.
Atmospheric	24 hours at 200°F (93°C).

Note: Cure times may require adjustment to compensate for heavy metal thickness, low exterior temperatures or other unusual factors. See Section 14 – Curing Instructions.



VE522WCN Enduraflex™ white, soft, top half chlorobutyl, bottom half pure gum (PG70) natural rubber for concentrated HCl and general purpose chemical services.

STORAGE LIFE FROM DATE OF SHIPMENT

32°F (0°C) to 50°F (10°C)	180 days
51°F (13°C) to 65°F (19°C)	90 days
66°F (21°C) to 75°F (23°C)	60 days
76°F (23°C) to 85°F (30°C)	30 days

Storage temperature must not exceed 85°F (30°C)

**ADHESIVE SYSTEM
ENDURABOND™ 1*2*3 SYSTEM**

1st coat on metal:	Primer #1
2nd coat on metal:	Intermediate #2
3rd coat on metal:	Tack #3 or 103 Tack
On backside of rubber:	Tack #3 or 103 Tack
On skives and seams:	103 Tack

*Each adhesive component requires thorough mixing before application.

APPLICATOR NOTES

1. The Tacky Back® version of this lining does not require an adhesive to be applied to the rubber except in seam areas.
2. Plying up layers of rubber lining thicker than 1/4" could result in the rubber flowing or sagging during cure. Test plate is required to determine flow characteristics.
3. The temperature of the substrate must be greater than 60°F (15°C) prior to applying primer and rubber. Temperatures should not exceed 120°F (49°C).
4. A heated table that warms rubber to approximately 120°F (49°C) is best for application.
5. Strict adherence to adhesive specifications is required. Tack time is critical to the success of the bond.



DISCLAIMER:

The above guidelines are based on general industry practices and not applicable to all installations. Please contact Blair Rubber Company for specific application instructions. Application methods shall conform to Blair Rubber Company instructions contained in the Engineering & Applicator manual. Deviations from the specifications must be approved in writing by Blair Rubber Company. Data values are approximate and may vary based on installation techniques and atmospheric conditions. As such, data values should be used as general guidelines and are not a legally binding warranty of product characteristics. This document is copyright to and the intellectual property of Blair Rubber Company and may not be copied or distributed without prior consent.